

ALPHA Key	Function	Numeric Keypad
(C)	Channel	(-)
(Backspace)	Clear	
(A)	ALL	(SHIFT)(-)
(F)	FRAME	
(I)	INVERT	(SHIFT)(/)
(L)	AT LEVEL	(+)
F2	SAVE	
F3	OPEN LIBRARY	
F8	UPDATE	
F7	RECORD	
(+)	ADD CHANNEL	(*)
	SUBSTRACT CHANNEL	(SHIFT)(*)
(T)	THRU	(/)
(CTRL)(F4)	TRACK	
(CTRL)(G)	GO	
(CTRL)(P)	PAUSE	
(CTRL)(B)	GO BACK	
(CTRL)(S)	Stage/Field mode	
(CTRL)(F)	FETCH	(SHIFT)(+)
PATCH		
(C)	C hannel	
(M)	Connect to d immer	
(D)	D immer	
(H)	Connect to C hannel	
(N)	Connect to C hannel	
(G)	G oto Next	
(V)	l ive mode	
(SPACE BAR)	<u>C</u> heck or <u>u</u> ncheck Channels / <u>d</u> immers in <u>l</u> ive mode.	-
-		-